

HANDING

MOUNTING

## **U653**

Folded Towel & Waste Combination Unit

JOB #:	
ITEM #:	

Revision 05/11

SIZE

TYPE

QUANTITY:

MOUNTING	HANDING	ITPE	SIZE	OTHER	
	584mm     1/2"	Adj Back  Adj Back  (12.7mm)  ded Waste  8"		7 1/4" 184 mm	-S4 4 1/4" 108mm -S2 2 1/4" 57mm

## **SPECIFICATIONS**

**Body:** Fabricated of #22 ga stainless steel with a #4 satin finish.

**Flange:** Fabricated of #22 ga stainless steel finished to match cabinet with 1/4" returns. (No miters or welds)

**Cabinet Back:** Fabricated of stainless steel formed for rigidity with multiple welds to cabinet body.

Cabinet Door: Fabricated of #22 ga stainless steel with #4 satin finish.

**Towel Dispenser:** Dispensing area has hemmed edges to prevent injury and towel tearing. Adjustable back allows c-fold and single-fold towels to be dispensed.

**Removable Waste:** #22 ga stainless steel #4 satin finish with all leading edges to have a radius. Unit is secured in place by a bottom bracket guide and top lock.

Hinge: Full length, heavy duty, stainless steel piano type hinge.

**Locks:** Pin tumbler commercial quality, keyed like all other AJW cabinets. **Collars:** Fabricated of #22 ga stainless steel, finished to match cabinet.

(Used when full recessing cannot be accomplished)

Overall Size: 17 1/4"W x 54"H x 8"D (wall depth req)

438mm x 1372mm x 203mm

Wall Opening: 15 3/4"W x 52 1/2"H x 7 1/2D

400mm x 1334mm

**U653-S2:** semi-recessed. with 2" collar, 5 1/2" wall opening 139mm **U653-S4:** semi-recessed. with 4" collar, 3 1/2" wall opening 88mm

U653-SM: Full surface mounted collar.

Towel Capacity: 600 c-fold, 800 multifold, 1200 singlefold

Waste Capacity: 12 gallons (1.6 cu ft)

Options:

-VL1: Reusable vinyl liner

## INSTALLATION

Coordinate installation with architect and contractor to avoid interference with pipes, vents, etc. Provide a rough wall opening 15 3/4"W x 52 1/2"H. See chart for required wall depth. If collar is required, slide collar over the back before installing into wall. Remove waste from cabinet and mount unit plumb and true in opening with proper fasteners per application. Secure waste in cabinet and load paper towels.

When cleaning cabinet use a non abrasive non-chloric solution and wiped off with the grain of the cabinet.

## NOTES