

U440 Waste Receptacle

JOB #:

ITEM #:

QUANTITY:

Revision 03/11

MOUNTING	HANDING	TYPE	SIZE	OTHER
Push Panel Door	2	30" 762 mm	98" - 46" (965 mm - 1168 mm) OMMENDED MOUNTING HEIGHT	s - S4 - T 102 mm - S2 - T 51 mm

Removable Waste

SPECIFICATIONS

Body: Fabricated of #22 gauge stainless steel with #4 satin finish on all exposed areas.

Door: #22 gauge, one piece stainless steel secured to body by means of a full length heavy duty stainless steel piano type hinge.

Push Door: #22 gauge stainless steel self closing door.

Flange Fabricated of: #22 gauge stainless steel finished to match cabinet. One piece construction without miters or welds with 1/4" returns

Removable Waste: Heavy duty pre-plated steel with large service handle for easy servicing.

Back: Fabricated of stainless steel formed for rigidity with multiple welds to cabinet.

Locks: Pin tumbler commercial quality type, keyed like all other AJW cabinets.

Collars: Fabricated of #22 gauge stainless steel sized and finished to match cabinet, surf mount & semi-recessed.

Overall Size: 17 1/4"W x 30"H x 6 1/4"D

438mm x 762mm x 159mm

Wall Opening: 15 3/4"W x 28 1/2"H x 6"D

400mm x 724mm x 152mm

U440-S2: semi-recessed with 4" (102mm) wall opening U440-S4: semi-recessed with 2" (51mm) wall opening

U440-SM: Surface Mounted

Waste Capacity: 6.5 gallons (.8 cu ft)

INSTALLATION

Coordinate installation with architect and contractor. Provide a wall opening 15 3/4"W x 28 1/2"H. Wall depth will vary will vary if collars are required. Open bottom door and remove waste from cabinet and insert in wall opening. Secure unit with proper fasteners per each application. Make sure unit is plumb. After unit has been secured, place waste back into cabinet and secure door.

NOTES